



JUMP STANDARD ASSEMBLY  
INSTRUCTIONS

800.611.6109

[www.horsejumps.net](http://www.horsejumps.net)



**Step #1**

Remove the items from the package and check the contents. See list of contents on the back page.



**Step #2**

Set the standard posts into the PolyPro jump feet.



**Step #3**

Attach washer to bolt and slide through the hole provided on the PolyPro foot and base of gate.



**Step #4**

Slide washer onto bolt on opposite side and attach the nut. Hand tighten as much as possible



**Step #5**

Use a ratchet or wrench to securely tighten nut. This will hold the feet onto the jump and create a rugged base of support.



**Repeat steps 3-5 on other side (foot) of the standard.**



**Step #6**

Slide the base plate over the underside of the PolyPro foot. If desired, sand or rocks can be placed inside the foot for additional weight prior to inserting the base plate.



**Step # 7**

Turn standard upright and **repeat instructions on the remaining standard.**

PACKAGE INCLUDES: 4 PolyPro Feet  
4 Bolts  
4 Nuts  
8 Washers